CR005V2 Sweex Internal Card Reader All-in-1 USB 2.0

Introduction

- Do not expose the Sweex Internal Card Reader All-in-1 USB 2.0 to extreme temperatures. Do not place the device in direct sunlight or in the direct vicinity of heating elements.
- Do not use the Sweex Internal Card Reader All-in-1 USB 2.0 in extremely dusty or moist surroundings.
- Protect the device against powerful shocks or jolts – they may damage the internal electronics.

Connecting the Sweex Card Reader

1. Ensure the computer is switched off and disconnected from the mains.
2. Open the computer casing and connect the cable to the 7-pin USB connection on your motherboard.
3. Close the computer casing and restart the computer.
4. Windows will automatically install the Sweex Card Reader. You can access the cards in the Sweex Card Reader via "My computer".



Warranty

All Sweex products are warranted for three years. We do not grant support or warranties for any software and/or (rechargeable) batteries included. Settlement of guarantee only takes place via the dealer where you have purchased the product in question.

The rightful owner has and retains title to all brand names and related rights mentioned in this manual.